


Model: PBS & PBT Parts List




NC Carpet Binding & Equipment Corp.
858 Summer Avenue
Newark, NJ 07104


USA: 973-481-3500 Email: sales@nccarpet.com
Fax: 1-973-481-0839 Canada: 1-800-336-1184




Part No.	Name of parts	Qty	Part No.	Name of parts	Qty
49-1	Face plate	1	163	Set screw for 161-1	3
50	Face plate hinge pin	1	182-1	Oil pin	3
51	Face plate hinge	1	204	Front plate	1
52	Set screw for 51	1	420	Tape guide A asm.	1
76	Tension dial assembly	1	421	Tape guide B asm.	1
77	Set screw for 76	1	422	Tape holder	1
78	Face plate thread guide	1	423	Tape holder shaft	1
79	Set screw for 78	2	426	Carrying handle	1
80	Arm thread guide	1	446	Set screw for 421	1
81	Set screw for 80	1	448-1	Set screw for 426	2
82	Spring washer for 81	1	461	Set screw for 420	1
83	Washer for 81	1	470	Washer for 420	1
151-1	Top plate	1	476	Caution note label B	1
152	Set screw for 151-1	2	507A	Thread guide tube	1
153	Top plate thread guide	1	525A-1	Spool holder asm.	1
154	Set screw for 153	1	601	Washer for 151-1	2
161-1	Belt cover	1	602	Set screw for 525A-1	1




Part No.	Name of parts	Qty	Part No.	Name of parts	Qty
1	Needle bar driving frame	1	30	Take-up lever crank	1
2	Needle bar driving frame pin	1	31	Set screw for 30	1
3	Snap ring for 2	1	32	Arm shaft crank	1
4	Collar for 2	1	33	Set screw(A) for 32	1
5	Set screw for 4	1	34	Spring pin for 32	1
6	Set screw for 2	1	35	Set screw(B) for 32	1
7	Zigzag driving crank spring	1	36	Arm shaft front bushing	1
8	Adjusting screw for 1	1	37	Set screw for 36	1
10	Set screw for 8	1	38	Arm shaft collar	1
13	Needle 435 #22	1	39	Set screw for 38	2
26	Needle bar connecting link	1	412	Needle bar	1
27	Needle bar connection stud	1	456	Set screw for 412	1
28	Take-up lever	1	603	Shim washer	1
29	Set screw for 28	1			




Part No.	Name of parts	Qty	Part No.	Name of parts	Qty
40	Worm gear	1	61	Crank rod	1
41	Set screw for 40	2	62	Crank rod hinge screw w/nut	1
42A	feed cum	1	63A	Forled rod	1
43	Set screw for 42A	1	65	Feed regulator slide block	1
44-1	Arm shaft back bushing	1	150-1	Zigzag driving crank	1
45	Hand wheel bushing	1	177	Zigzag driving crank guide	1
46	Set screw for 45	1	201-1	Unit frame assembly	1
47	Spring pin for 45	1	203	Set screw for 201-1	3
48-1	Arm shaft	1	436	V-belt	1
54	Hand wheel	1	459	Set screw for 54	2
55	Stop motion screw	1	519	Feed driving eccentric cam	1
56	Stop motion clamp screw	1	544	Set screw for 519	1
57	Stop motion washer	1			




Part No.	Name of parts	Qty	Part No.	Name of parts	Qty
14	Presser regulator	1	518	Hinge screw	1
20	Presser bar spring bracket	1	532NS	Set screw for 604	4
21	Set screw for 20	1	536NS	Set screw for 512NS	1
22	Presser foot lifter	1	542	Set screw for 517-1	2
23	Presser foot lifter hinge stud	1	543	Set screw for 506	4
403	Roller	1	543-1	Set screw for 563	3
404	Roller bracket	1	545	Nut	1
406	Presser bar	1	549-1	Set screw for 515NS	2
442	Presser spring	1	557	Washer for 512NS	1
449	Set screw for 404	1	558	Supporting screw for 512NS	1
450	Set screw for 403	2	560	Joint pin	1
505NS	Connecting shaft	1	561	Washer for hinge screw 518	1
506	Joint	1	562	Washer for hinge screw 518	1
510	Roller shaft	1	563	Clutch shaft connector	1
512NS	Clutch shaft	1	604	Clutch connecting crank	1
513NS	Clutch	1	605	Clutch holder base	1
515NS	Clutch holder asm.	1	606	Set screw for 515NS	2
517-1	feed driving shaftconnecting rod	1			



Part No.	Name of parts	Qty				
64	Forked rod hinge screw w/nut	1				
128	Feed rock shaft asm.	1				
129	Screw center w/nut for 128	2				
131	Set screw for 419	2				
137	Feed crank asm.	1				
138	Spring holder w/spring for 137	1				
139	Set screw for 137	1				
140	Set screw for 138	1				
418	Feed dog	1				
419	Needle plate	1				
440	Binder plate	1				
443	Set screwfor 418	2				
454	Set screwfor 440	1				
644	Set screw for Attachment	1				
645	Set screw for Attachment	1				
646	Washer for Attachment	2				




Part No.	Name of parts	Qty	Part No.	Name of parts	Qty
101	Shuttle race	1	119	Lower shaft	1
102	Shuttle race retaining ring	1	120	Lower shaft front bushing	1
102S	Race cap spring	1	121	Set screw for 120	2
103	Set screw for 101	1	122	Lower shaft cam	1
105NS	Shuttle driver shaft shuttle driver	1	123	Set screw for 122	1
106	Shuttle driver shaft bushing	1	124	Lower shaft back bushing	1
107	Set screw for 106	1	125	Set screw for 124	1
108	Shuttle driver shaft collar	1	126	Lower shaft crank	1
109	Set screw for 108	2	127	Set screw for 126	2
110	Shuttle driver shaft bevel gear	1	130	Shuttle cleaner	1
111	Set screw (A) for 110	1	133	Gear box cover	1
112	Set screw (B) for 110	1	134	Plastic packing	1
113	Lower shaft bevel gear	1	135	Set screw for 133	3
114	Set screw (A) for 113	1	176	Washer for 119	2
115	Set screw (B) for 113	1	607	Thrust collar	2
116	Shuttle hook	1	608	Set screw for 608	4
117	Bobbin case	1	609	Washer for 126	2
118	Shuttle driving spring	1			




Part No.	Name of parts	Qty	Part No.	Name of parts	Qty
166-1	LED light asm.	1	477	Band	5
167	Set screw for 166-1	2	478	Closed-end connector	2
178-1	Switch	1	553	Motor 115V 120W	1
427-1	Switch handle	1	610	Set screw for 435-1	2
428-1	Switch handle cover	1	611	Washer for 435-1	2
429NS	Switch	1	612	Spring washer for 435-1	2
430	Caster A	1	613	Set screw for 474NS	1
431-1	Caster B	1	614	Closed-end connector	2
432NS	Caster C	1	615	Cord clamp (nk-8n)	1
433	Large gear asm. (in needle bearing)	1	616	Set screw for 615	1
434	Small gear	1	617	Insulation sheet	1
435-1	Motor bracket	1	618	Set screw for 427-1	4
437	Large gear shaft	1	619	Screw(set)	1
438NS	Connector cable	1	620	Nut	1
445	Set screw for 428-1	2	621	Cord clamp (nk-6n)	1
451	Set screw for 434	1	622	Set screw for 621	1
452	Washer for 433	1	623	Power supply	1
453NS	Set screw for 432NS	2	624	Power supply bracket	1
458	Set screw for 429NS	2	625	Set screw for 624	2
467	Nut for 433	1	626	Washer for 624	2
474NS	Plate	1	627	Set screw for caster A & B	2
475NS	Bush	1	628	Washer for caster A & B	2

ACCESSORIES




Part No.	Name of parts	Qty				
301	Accessory box	1				
302	Screwdriver-small	1				
303	Screwdriver-large	1				
305	Needle (5 pieces)	1				
306	Tweezers	1				
308	Hexagonal wrench (3mm)	1				
309	Hexagonal wrench (4mm)	1				
310	Hexagonal wrench (2mm)	1				
629	Oiler asm.	1				
630	Spanner	1				
631	Hexagonal wrench (2.5mm)	1				

EXCLUSIVE PARTS FOR MODEL PBT



Part No.	Name of parts	Qty	Part No.	Name of parts	Qty
501	Presser spring regulator screw	1	530	Face plate hinge pin	1
502-1	Top plate	1	531	Hand lifter B	1
503-1	Face plate	1	534	Set screw for 527	1
508-1	Roller base asm.	1	539-1	Set screw for 508-1	2
511	Presser bar	1	552-1	Oil pin for 502-1	3
521-1	Lower roller plate	1	540	Set screw for 526	1
522	Lower roller	1	541	Set screw for 524	1
523	Lower roller shaft	1	547	Set screw for 521-1	2
524	Presser lifter lever	1	632	Washer for 508-1	1
526	Presser bar guide bracket	1	633	Dust cover	1
527	Hand lifter pin	1	634	Set screw for 633	1
528	Presser spring	1			



Part No.	Name of parts	Qty		Part No.	Name of parts	Qty
504	Roller	1		549-1	Set screw for 637	2
505NS	Connecting shaft	1		557	Washer for 512NS	2
506	Joint	1		558	Supporting screw for 512NS	2
509-1	Roller bracket	1		560	Joint pin	1
510	Roller shaft	1		563	Clutch shaft connector	1
512NS	Clutch shaft	2		604	Clutch connecting crank	1
513NS	Clutch	2		606	Set screw for 515NS & 635	6
515NS	Clutch holder asm.	1		635	Clutch holder	1
516-1	Clutch connecting crank	1		636	Set screw for 512NS	1
529-1	Hand lifter A	1		637	Clutch holder base	1
532NS	Set screw for 516-1	8		638	L-ball	1
533-1	Set screw for 509-1	2		639	Nylon nut	2
535	Set screw for 504	2		640	Rod	1
536NS	Set screw for 512NS	1		641	Nut for 640	2
543	Set screw for 506	4		642	HINGE SCREW	1
543-1	Set screw for 563	3		643	BRACKET	1

NUMERICAL INDEX FOR PBS/PBT PARTS BOOK

<u>PART NO.</u>	<u>PAGE:</u>	<u>PART NO.</u>	<u>PAGE:</u>
1	PAGE 2	52	PAGE 1
2	PAGE 2	54	PAGE 3
3	PAGE 2	55	PAGE 3
4	PAGE 2	56	PAGE 3
5	PAGE 2	57	PAGE 3
6	PAGE 2	61	PAGE 3
7	PAGE 2	62	PAGE 3
8	PAGE 2	63A	PAGE 3
10	PAGE 2	64	PAGE 5
13	PAGE 2	65	PAGE 3
14	PAGE 4	76	PAGE 1
20	PAGE 4	77	PAGE 1
21	PAGE 4	78	PAGE 1
22	PAGE 4	79	PAGE 1
23	PAGE 4	80	PAGE 1
26	PAGE 2	81	PAGE 1
27	PAGE 2	82	PAGE 1
28	PAGE 2	83	PAGE 1
29	PAGE 2	101	PAGE 6
30	PAGE 2	102S	PAGE 6
31	PAGE 2	102	PAGE 6
32	PAGE 2	103	PAGE 6
33	PAGE 2	105NS	PAGE 6
34	PAGE 2	106	PAGE 6
35	PAGE 2	107	PAGE 6
36	PAGE 2	108	PAGE 6
37	PAGE 2	109	PAGE 6
38	PAGE 2	110	PAGE 6
39	PAGE 2	111	PAGE 6
39	PAGE 1	112	PAGE 6
40	PAGE 3	113	PAGE 6
41	PAGE 3	114	PAGE 6
42A	PAGE 3	115	PAGE 6
43	PAGE 3	116	PAGE 6
44-1	PAGE 3	116-1	PAGE 7
45	PAGE 3	117	PAGE 6
46	PAGE 3	118	PAGE 6
47	PAGE 3	119	PAGE 6
48-1	PAGE 3	120	PAGE 6
49-1	PAGE 2	121	PAGE 6
50	PAGE 2	122	PAGE 6
51	PAGE 1	123	PAGE 6

NUMERICAL INDEX FOR PBS/PBT PARTS BOOK

<u>PART NO.</u>	<u>PAGE:</u>	<u>PART NO.</u>	<u>PAGE:</u>
124	PAGE 6	418	PAGE 5
125	PAGE 6	419	PAGE 5
126	PAGE 6	420	PAGE 2
127	PAGE 6	421	PAGE 1
128	PAGE 5	422	PAGE 1
129	PAGE 5	423	PAGE 1
130	PAGE 6	426	PAGE 1
131	PAGE 5	427-1	PAGE 7
133	PAGE 6	428	PAGE 7
134	PAGE 6	429NS	PAGE 7
135	PAGE 6	430	PAGE 7
137	PAGE 5	431-1	PAGE 7
138	PAGE 5	432NS	PAGE 7
139	PAGE 5	433	PAGE 7
140	PAGE 5	434	PAGE 7
150-1	PAGE 3	435-1	PAGE 7
151-1	PAGE 2	436	PAGE 3
152	PAGE 1	437	PAGE 7
153	PAGE 1	438NS	PAGE 7
154	PAGE 1	440	PAGE 5
161-1	PAGE 1	442	PAGE 4
163	PAGE 1	443	PAGE 5
167	PAGE 7	445	PAGE 7
176	PAGE 6	446	PAGE 1
177	PAGE 3	448-1	PAGE 1
178-1	PAGE 7	449	PAGE 4
182-1	PAGE 1	450	PAGE 4
201-1	PAGE 3	451	PAGE 7
203	PAGE 3	452	PAGE 7
204	PAGE 1	453NS	PAGE 7
301	PAGE 8	454	PAGE 5
302	PAGE 8	456	PAGE 1
303	PAGE 8	458	PAGE 7
305	PAGE 8	459	PAGE 3
306	PAGE 8	461	PAGE 2
308	PAGE 8	467	PAGE 7
309	PAGE 8	470	PAGE 1
310	PAGE 8	474NS	PAGE 7
403	PAGE 4	475NS	PAGE 7
404	PAGE 4	476	PAGE 1
406	PAGE 4	477	PAGE 7
412	PAGE 1	478	PAGE 7

NUMERICAL INDEX FOR PBS/PBT PARTS BOOK

<u>PART NO.</u>	<u>PAGE:</u>	<u>PART NO.</u>	<u>PAGE:</u>
501	PAGE 9	539-1	PAGE 9
502-1	PAGE 9	540	PAGE 9
503-1	PAGE 9	541	PAGE 9
504	PAGE 10	542	PAGE 4
505NS	PAGE 4	543	PAGE 4
505NS	PAGE 10	543	PAGE 10
506	PAGE 4	543-1	PAGE 4
506	PAGE 10	544	PAGE 3
507A	PAGE 1	545	PAGE 4
508-1	PAGE 9	547	PAGE 9
509-1	PAGE 10	549-1	PAGE 4
510	PAGE 4	549-1	PAGE 10
510	PAGE 10	552-1	PAGE 9
511	PAGE 9	553	PAGE 7
512NS	PAGE 4	557	PAGE 4
512NS	PAGE 10	557	PAGE 10
513NS	PAGE 4	558	PAGE 4
513NS	PAGE 10	558	PAGE 10
515NS	PAGE 4	560	PAGE 4
515NS	PAGE 10	560	PAGE 10
516-1	PAGE 10	561	PAGE 4
517-1	PAGE 4	562	PAGE 4
518	PAGE 4	563	PAGE 4
519	PAGE 3	563	PAGE 10
521-1	PAGE 9	601	PAGE 1
522	PAGE 9	602	PAGE 1
523	PAGE 9	603	PAGE 1
524	PAGE 9	604	PAGE 4
525A-1	PAGE 1	604	PAGE 10
526	PAGE 9	605	PAGE 4
527	PAGE 9	606	PAGE 10
528	PAGE 9	607	PAGE 6
529-1	PAGE 10	608	PAGE 6
530	PAGE 9	609	PAGE 6
531	PAGE 9	610	PAGE 7
532NS	PAGE 4	611	PAGE 7
532NS	PAGE 10	612	PAGE 7
533-1	PAGE 10	613	PAGE 7
534	PAGE 9	614	PAGE 7
535	PAGE 10	615	PAGE 7
536NS	PAGE 4	616	PAGE 7
536NS	PAGE 10	617	PAGE 7

NUMERICAL INDEX FOR PBS/PBT PARTS BOOK

<u>PART NO.</u>	<u>PAGE:</u>
618	PAGE 7
619	PAGE 7
620	PAGE 7
621	PAGE 7
622	PAGE 7
623	PAGE 7
624	PAGE 7
625	PAGE 7
626	PAGE 7
627	PAGE 7
628	PAGE 7
629	PAGE 8
630	PAGE 8
631	PAGE 8
632	PAGE 9
633	PAGE 9
634	PAGE 9
635	PAGE 10
636	PAGE 10
637	PAGE 10
638	PAGE 10
639	PAGE 10
640	PAGE 10
641	PAGE 10
642	PAGE 10